



DESIGN <i>[Signature]</i>	DRAWN BY <i>RF</i>	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED <i>[Signature]</i>	APPROVED <i>[Signature]</i>	DRAWING NO. DSI 9172	REV. A SHEET 1 OF 1
DATE 99.11.02		TITLE WEARPAD KITS	SCALE NTS
A	99.11.02	NEW ISSUE	

# **DART SERVICE INSTRUCTION**

TO AMEND INSTALLATION INSTRUCTIONS: D206-642

IIN-D350-636

IIN-D058-672

IIN-D315-668

Qty -105	Qty -205	Qty -107	Qty -207	Part Number	Description
X				DSI 9172-105	SURFACITE™ WEARPAD KIT
	X			DSI 9172-205	STD. TUNGSTEN CARBIDE WEARPAD KIT
		X		DSI 9172-107	SURFACITE™ WEARPAD KIT
			X	DSI 9172-207	STD. TUNGSTEN CARBIDE WEARPAD KIT
	5		7	D2648-3	WEARPAD
5		7		D2648-7	WEARPAD
20	20	28	28	MS27039-1-08	SCREWS
20	20	28	28	AN960JD10L	WASHERS

## **NOTES:**

- 1) D2648-5 CAN BE REPLACED BY D2648-3.
- 2) IN THE DSI 9172 -105/ -107 KTS, THE D2648-7 WEARPADS REPLACE THE D2648-3 AND D2648-5 WEARPADS SHOWN IN THE INSTALLATION INSTRUCTIONS.
- 3) THE ABOVE KITS CAN BE INSTALLED ON DART 206 A/B, 206L/L1/L3/L4, 407, OH-58 A/A+/C, AS 350/355, AND SA 315B SKIDTUBES ACCORDING TO THE FOLLOWING TABLE:

KIT	CAN BE INSTALLED ON
DSI 9172-105 DSI 9172-205	D206-642-111/ -112 D206-642-211/ -212/ -213/ -214 D350-636-011/ -012/ -013/ -014 D315-668-011/ -012 D058-672-011/ -012/ -013/ -014
DSI 9172-107 DSI 9172-207	D206-642-311/ -312 D206-642-411/ -412

- 4) INSTALLATION OF THE DSI 9172 -105 KIT WILL ADD 0.95 lbs (0.43 kg) TO THE WEIGHT OF THE SKIDTUBE.
- 5) INSTALLATION OF THE DSI 9172 -107 KIT WILL ADD 1.33 lbs (0.60 kg) TO THE WEIGHT OF THE SKIDTUBE.